			**/12 Part Number	**/20 Part Number
103	Cover, drive end	1		
104	Cover, non-drive end	1		
109	Casing	1		
137.1	Port plate, drive end	1		
137.2	Port plate, non-drive end	1		
	Manifold	2		
210	Shaft	1		
230	Impeller	1		
235.1	Compensating ring	4		
238.1	Spacer ring	2		
238.1	Spacer ring	2		
321	roller bearing	1		
322	ball bearing	1		
330	Greaser	2		
357/.1	Bearing housing	2		
360	Valve plate	2		
360.1	Valve spacer	6		
364	Mechanical seal cover	2		
400	Flange gasket	4		
404	O-Ring	. 2		
407/.1	Liquid gasket	1		
407.1	Cover-plate gasket	2		
407	Plate-casing gasket	2		
435	Valve	2		
436	Mechanical seal, drive end	1		
437	Mechanical seal, non-drive end	1		
507	V-Seal	2		
507.1	V-Seal	1		
562	Locating pin	2		
563	Screw	24		
563	Screw	8		
563.4	Nut	24		
603	Bearing cover, drive end	1		
604	Bearing cover, non-drive end	1		
804	Screw	8		
807	Screw	8		
844	Impeller nut	1		
844.2	Screw	2		
845	Bearing nut			
845.1	Washer	1		
863	Screw	8		
902	Screw	6		
906	Rod	8		
915.2	Plug	8		
921	Nut	16		
945	Coupling key	1		
946	Impeller key	1		
	Repair Kit	1		
	Kit of nuts and bolts	1		